DVD CAM Software Support Center

Software Tutorials
Driver Installation Manual: How to install Hitachi driver(DZ-MV270)

Installing Hitachi Device Drivers for DZ-MV270

1. *Terminate all the applications and insert the installation CD to the CD-ROM drive of your PC. If any anti-virus software is running, deactivate the software during the installation.*
2. *Insert your DVD-RAM disc that contains video or photo into the drive of Hitachi DVD video camera / recorder and power on Hitachi DVD video camera / recorder to the position of "VIDEO" or "PHOTO".*
3. *Connect PC and Hitachi DVD video camera / recorder using USB cable. For your PC, be sure to connect to the unused USB port on the back of your PC. The red CHARGE/ACCESS indicator will be turned off following with beeping sound. At this time, the CHARGE/ACCESS indicator is black and LCD and viewfinder are off. Your PC should recognize Hitachi DVD video camera / recorder as "Found New Hardware".*
4. *The "Found New Hardware Wizard" dialog box should appear on your PC. Follow the instructions to complete the installation referring to the Step-by-Step example below.'*

Step-by-Step Example for Windows XP:

(a) PC recognizes the New Hardware attached to PC as the following in the task bar on the right below corner.

(b) The Wizard dialog box appears to install the USB driver. Select "Install from a specific location".


Found New Hardware Wizard
Welcome to the Found New Hardware Wizard
This wizard helps you install software for:
DVDCAM DZ-MV270 Series
If your hardware came with an installation CD or floppy disk, insert it now.
What do you want the wizard to do?
Install the software automatically (Recommended)
Install from a list or specific location (Advanced)
Click Next to continue.
< Back
Next >
Cancel

(c) Specify the location by selecting the "Browse" button and select ¥Drivers¥Win2K_XP folder in CD and go to "Next". For Hardware Installation warning dialog box, select "Continue Anyway".


Found New Hardware Wizard
Please choose your search and installation options.
Search for the best driver in these locations.
Use the check boxes below to limit or expand the default search, which includes local paths and removable media. The best driver found will be installed.
Search removable media (floppy, CD-ROM...)
Include this location in the search:
D:\Drivers\Win2K_XP
Browse
Don't search. I will choose the driver to install.
Choose this option to select the device driver from a list. Windows does not guarantee that the driver you choose will be the best match for your hardware.
< Back
Next >
Cancel
Browse For Folder
Select the folder that contains drivers for your hardware.
DZMV270AE (D:)
Drivers
Win2K_XP
Win98
WinMe
IW
DVD Drive (E:)
Shared Documents
To view any subfolders, click a plus sign above.
OK
Cancel
Hardware Installation
The software you are installing for this hardware:
Hitachi DVDCAM(DZ-MV270) USB Interface
has not passed Windows Logo testing to verify its compatibility with Windows XP. (Tell me why this testing is important.)
Continuing your installation of this software may impair or destabilize the correct operation of your system either immediately or in the future. Microsoft strongly recommends that you stop this installation now and contact the hardware vendor for software that has passed Windows Logo testing.
Continue Anyway
STOP Installation

(d) The installation should proceed as the following.


Found New Hardware Wizard
Please wait while the wizard installs the software...
Hitachi DVDCAM(DZ-MV270) USB Interface
Setting a system restore point and backing up old files in case your system needs to be restored in the future.
< Back
Next >
Cancel
Found New Hardware Wizard
Please wait while the wizard installs the software...
Hitachi DVDCAM(DZ-MV270) USB Interface
USBSTOR.SYS
To C:\WINDOWS\system32\drivers
< Back
Next >
Cancel

(e) USB driver installation is completed with the dialog box below. At task bar, the message "Your new hardware is installed and ready to use" appear.


Found New Hardware Wizard
Completing the Found New Hardware Wizard
The wizard has finished installing the software for:
Hitachi DVDCAM(DZ-MV270) USB Interface
Click Finish to close the wizard.
< Back
Finish
Cancel
Found New Hardware
Your new hardware is installed and ready to use.
1:48 PM

(f) To remove the attachment to the PC, click the green arrow icon at task bar and select the text, "Safely remove Hitachi DVDCAM(DZ-MV270) USB Interface –Drive(F:)"

Or double-click the arrow icon at task bar and select "Stop" button.


Safely Remove Hardware
Select the device you want to unplug or eject, and then click Stop. When Windows notifies you that it is safe to do so unplug the device from your computer.
Hardware devices:
Hitachi DVDCAM(DZ-MV270) USB Interface
Hitachi DVDCAM(DZ-MV270) USB Interface at DVDCAM DZ-MV270 Series
Properties
Stop
Display device components
Close

(g) For the confirmation of the installation, check device manager. (Path: Start → Control Panel → Administrative Tools → Computer Management) Double click "Hitachi DVDCAM(DZ-MV270) USB Interface" to check the device status whether the device is working properly.



Step-by-Step Example for Windows 98/98SE:

(a) PC recognizes the New Hardware attached to PC and "Create driver database" message appear. Next, the Wizard dialog box appears to install the USB driver. Go to Next.

Add New Hardware Wizard
This wizard searches for new drivers for:
DVDCAM DZ-MV270 Series
A device driver is a software program that makes a hardware device work.
< Back
Next >
Cancel

Select "Search for the best driver for your device (Recommended)" and go to Next.

Add New Hardware Wizard
What do you want Windows to do?
Search for the best driver for your device. (Recommended).
Display a list of all the drivers in a specific location, so you can select the driver you want.
< Back
Next >
Cancel

(b) Specify the location by selecting the "Browse" button and select ¥Drivers¥Win98 folder in CD.

Add New Hardware Wizard
Windows will search for new drivers in its driver database on your hard drive, and in any of the following selected locations. Click Next to start the search.
Floppy disk drives
CD-ROM drive
Microsoft Windows Update
Specify a location:
D:\Drivers\Win98
Browse...
< Back
Next >
Cancel



(c) As a result, Windows found the driver as below. Go to Next

Add New Hardware Wizard
Windows driver file search for the device:
Hitachi DZ-MV270 USB Interface
Windows is now ready to install the best driver for this device.
Click Back to select a different driver, or click Next to continue.
Location of driver:
D:\DRIVERS\WIN98\DZMV270.INF
< Back
Next >
Cancel

(d) Select "Finish" button.


Add New Hardware Wizard
Hitachi DZ-MV270 USB Interface
Windows has finished installing the software that your new hardware device requires.
< Back
Finish
Cancel

(e) To remove the attachment to the PC, open My Computer or Windows Explorer and select the drive where Hitachi DVD video camera /recorder is recognized as a drive. Right-click and select "Eject" to detach the device.



(f) For the confirmation of the installation, check device manager. (Path: Start → Control Panel → System) Double click "Hitachi DVDCAM(DZ-MV270) USB Interface" to check the device status whether the device is working properly.